(The following is sloping edge as an example.)

A. Power strip

B. Cable hole cover

C. Aluminum sloping edge

• Cable hole cover
(bottom)

Lock

Unlock

The clear PC cover plate

Printed sheet

1.Lay the floor motherboard with holes, screen, PC board and aluminum edge strip in turn.
(Determine the laying position of this platform according to your actual use needs.)

2. Insert the outer ring of the cable hole cover into the floor hole.

3. Insert the plug into the floor from the top down.

4.Pick up the perforated aluminum edge strip and route the cable through the trough at the bottom of the floor.
When the plug comes out,put back the aluminum trim.

5.Insert the rubber trap on the cover of the threading hole into the cable.

6.Close the lid and rotate until locked.