



## SAGE DISPLAY SYSTEMS ACRYLIC BROCHURE HOLDER

(Only for selected models)

### STEP 1

Remove the cover at the top of the pole  
(All of our sage accessories use the channels on  
the pole to attach the accessories).

(a) Simply loosen connector with the screw located  
at the bottom of the bar on the holder then slide the  
connectors along the channel.

(b) Tighten screw at the desired height.

### STEP 2

To attach U bracket to clip frame and then slide the  
bracket along the channel on the display pole. Adjust  
to appropriate height and tighten.